FW1179 User's Manual

(Product Guide)

Version 4.14(Rev.E)

March 30, 2012



Class A Digital Device (industrial & commercial environment)

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to CE and FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

FW1179 User's Manual

Document Part Number: M4066-01 Document Version: 4.14(Rev.E) Revised: March 30, 2012

About This Document

This document is prepared for users of FW1179 supplied by Seyeon Tech Co., Ltd. It is assumed that the users are familiar with Microsoft Windows operating systems and Web browsers such as Internet Explorer. It is also assumed that the users are well aware of how to install and use the network equipment such as LAN, Hub, router, and having basic knowledge of network terminologies. If you have any questions regarding network installations, please contact your network equipment vendor or network administrator or Internet service providers.

For updated contents, detailed features and other applications from Seyeon Tech, please refer to the user's manual in CD-ROM provided with the product you purchased, or visit Seyeon Tech's Internet homepage at http://www.flexwatch.com/.

Copyright Notice

Copyright © 2012 Seyeon Tech Co., Ltd. All rights reserved. No part of this document may be reproduced in any form or by any means without the prior written permission of Seyeon Tech Co., Ltd.

Disclaimer

Seyeon Tech Co., Ltd. (Seyeon Tech) Makes no representations or warranties with respect to the contents hereof. In addition, information contained herein is subject to change without notice. Every precaution has been taken in the preparation of this manual, nevertheless, Seyeon Tech assumes no responsibility for errors or omissions or any damages resulting from the use of the information contained in this document.

Trademarks

FlexWATCH[®] and FlexWATCH[®] Logo are trademarks of Seyeon Tech Co., Ltd. Windows and Internet Explorer are a trademark of Microsoft Corporation. All other trademarks belong to their respective owners.

Technical Support

For technical support call, email, or visit our web site. Telephone: +82-2-2192-6840~1 Email: <u>sales@flexwatch.com</u> Web site: <u>http://www.flexwatch.com</u> or <u>http://www.seyeon.co.kr</u>

Contents

1. PR	ODUCT OVERVIEW	4
1.1.	FW1179	4
1.2.	Key Features	5
1.3.	TECHNICAL SPECIFICATION	6
1.4.	FW1179 Packing List	8
2. HA	ARDWARE DESCRIPTION	9
2.1.	Main Body View	9
2.1.	Full View	10
3. FV	V1179 INSTALLATION AND BASIC SETUP	11
3.1.	Before Installation	11
3.2.	Factory Default Settings	11
3.3.	Installing FW1179	11

1. Product Overview

1.1. FW1179

FlexWATCH® 1179 is a stand-alone device transmitting vdeo from built-in megapixel camera over IP(Internet Protocol) network. There is one type of FW1179 model: MV.

It can transmit up to 30fps@1.3M over the existing network. You can monitor video of FW1179 through web browser(ie. MS Internet Explorer), if FW1179 is connected to network. FW1179 supports video compression both Motion-JPEG and H.264 simultaneously so that user can choose appropriate video compression for the purpose. For both Motion-JPEG and H.264, FW1179 provides 6 levels of video quality. FW1179 also supports both ONVIF and PSIA.



Picture 1 : FW1179

1.2. Key Features

- Standalone device with a built-in web server
- 100M Auto-Sensing Ethernet
- Configuring and controlling through Web browser
- Max 30 fps transmission speed on TCP/IP network
- Effective Bandwidth & Bit-rate Control (VBR/CBR) by H.264
- Supports Dual Streaming in Motion JPEG and H.264
- Support Dynamic IP network by IPCCTVDNS Server
- Support Transparent Mode
- Support SNMP function
- Encryption function by user authentication
- Image transmission function via FTP and Email
- Support both ONVIF/PSIA

1.3. Technical Specification

	FW1179-MV
Hardware	32bit Embedded CPU NAND Flash 128Mbytes / DDR2: 128Mbytes Linux version 2.6.xx operating system Battery backed up real-time clock
Image sensor	 1/3" progressive scan MOS Active pixels 1280H x 1024V, 1.31M Effective pixels 1376H x 1070V, 1,47M Pixel size: 3.75 (H) μm x 3.75 (V) μm Color filter Bayer arrangement of primary colors: R, G, B Bit number of internal ADC: 12 bits Parallel output: 54 MHz, 12 bits Output frame rate per second: 30fps Full scan mode: 1.3 mega pixel output
Lens	Auto IRIS & Vari-focal 3.6 - 16.0 mm F1.2
IR Illuminator	50pcs 850nm Infrared LEDs 30°IR Range, maximum 30m IR distance
Minimum illumination	Color: 0.1 Lux (F1.0) B/W: 0.01 Lux (F1.0) (TDN) 0.02 Lux (F1.0) (without TDN)
Video related special functions	Day & Night (Auto/B&W/Off) Auto White Balance Noise Filter (Off/On) Brightness/Contrast/Sharpness/AGC Gain Control Lens Type (DC/Manual) Shutter (Manual/Auto) Vertical/Horizontal Flip Frequency Control (50/60)
Video compression	Motion JPEG H.264
Video standards	ONVIF PSIA
Resolution	1280x1024, 704x480, 320x240, 160x112
Frame rate (each channel)	Motion JPEG: Up to 30 fps @ 1280H x 1024V (Other Stream at QCIF) H.264: Up to 30 fps @ 1280H x 1024V (Other Stream at QCIF)
Video Streaming	Motion JPEG and H.264 Dual Streaming (Simultaneously) Controllable frame rate and bandwidth
Image setting	Compression levels: 6 (Motion-JPEG, H.264) Color: color, black & white
LAN interface	100BaseT Ethernet auto sensing IEEE 802.3af Built-in POE (optional) IEEE 802.11b/g Built-in wireless (optional)
Security features	Multi user level protection for camera access

FW1179 User's Manual

Advanced Service	Up to 5.6M memory for Pre/Post alarm buffer E-Mail, FTP, IP notification, Alarm Notification to e-mail CGI Call by event or schedule
Built-in Motion detections	Accuracy: 12x12=144 blocks Motion Sensitivity : -100 ~ 100 : 100 is hypersensitive
Management	Configurable by serial, web or telnet Remote system update via telnet, FTP OR web browser
Developer support	Provides HTTP CGI API ActiveX control development kit
PWR Supply	SMPS Input: 100~240VAC, AC 50/60Hz, 1.2A Output : DC 12 Volt, 3A
PWR Consumption	DC 12Volt Max 900mA at night
Operating Environment	Temperature : 32°~ 122年 (0°~ 50℃) Humidity : 20 ~ 80% RH(non-condensing)
Miscellaneous	Freely downloadable NDVR Software Work with FW-Manager(NDVR S/W) Dynamic IP support through IPCCTVDNS
Simultaneous users	Live-cast for up to 16 clients
Installation, management and maintenance	Installation CD and web-based configuration Firmware upgrades over HTTP, telnet & FTP, firmware available at www.flexwatch.com
Video access from Web browser	Video access from Web browser
Minimum Web browsing requirements	Pentium 4, 2 GHz, 2GB(RAM) or higher Video Card: 256MB RAM, 1024x768 resolution or higher 100Mbps Network Adaptor or faster Windows XP Pro or later Internet Explorer 6.x or later
System integration support	Powerful API for software integration available at http://www.flexwatch.com, including Simple Viewer API, FlexWATCH Control SDK, event trigger data in video stream, embedded scripting and access to serial port peripherals over HTTP/TCP User can be installed user program daemon for event notification or sending image Embedded operating system: Linux 2.6
Supported protocols	HTTP, RTP/RTSP, TCP/IP, FTP, Telnet, RARP, PPPoE, SNMP, PAP, CHAP, DHCP, NTP, SMTP client
Approvals	KC FCC : Class A CE : Class A RoHS
Dimensions (HxWxD) and weight (1lbs = 454g)	92.8Ø x 235.8(L) x 125.8(H) (in mm) About 1.1kg without power supply
	* All specifications are subject to change without prior potice

* All specifications are subject to change without prior notice.

Table 1 : FW1179 Data Sheet

1.4. FW1179 Packing List

FW1179-MV	1ea	
Power Supply Unit (Power Cable & SMPS DC12V 1.0A Adapter)	1ea	
CD (User's Manual, installation wizard and etc)	1ea	

Table 2 : FW1179 Packing List

Note: Please check all the listed items are included in your package. For any missing items, please contact your local distributor.

2. Hardware Description

2.1. Main Body View



Picture 2 : Front View

	Name	Description
А	IR LED	50pcs 850nm Infrared LEDs.
В	Lens	Lens for board mount
С	Sunshield	Top covering Sunshield

Table 3 : FW1179 Main Body View

2.1. Full View



Picture 3 : FW1179 Full View

	Name	Description
А	Main body	Mainbody
В	Mounting Bracket	Mounting bracket
С	LAN	LAN Connector.
D	Power Conn.	Power Connector.

Table 4 : FW1179 Full View

3. FW1179 Installation and Basic Setup

3.1. Before Installation

- Read carefully User's Manual.
- Check User's Network (IP Address, Network Mask and default gateway)
- Secure IP address for FW1179.

3.2. Factory Default Settings

The following table shows the factory default condition. Please refer to this when you need to change the values on admin menu.

	Factory Default	
Admin ID	root	
Admin password	root	
IP address	10.20.30.40	
Network mask	255.255.255.0	
Gateway	10.20.30.1	
Wireless LAN (Option)	Disabled	
Table 5 - Fastam Default		

Table 5 : Factory Default

Note: Factory default Admin ID and Password are all lower case letters. You can change the password with Capital letters.

3.3. Installing FW1179

Following steps are the physical installation process for FW1179.

- 1. Fix the FW1179 in place
- 2. Connect the FW1179 to the Internet cable through the LAN port.
- 3. Connect the power supply of FW1179.

After that, you need to follow the steps below.

- Network Configuration: Refer to "IP Installer User's Manual"
- Camera Configuration: Refer to "FlexWATCH Admin Menu User's Manual"
- Service Configuration: Refer to "FlexWATCH Admin Menu User's Manual"